



SENSOR

MIXERS

COMFORTABLE
SOLUTIONS

SENSOR MIXERS

WITH A TOUCHLESS WATER TRIGGER FUNCTION

HEALTH

| Washbasin mixers with an automatic touchless water trigger function stand for the highest level of hygiene, which is especially important in toilets located in public areas, such as shopping malls, offices or health centres.

ERGONOMICS AND FUNCTIONALITY

| A comfortable water agitator with a temperature adjustment function is included in the set.

| The elongated shape of the mixer spout provides the user with freedom of movement when washing hands.

| The mixer set also includes a special wrench for the aerator, thanks to which it can be disassembled for cleaning only by dedicated personnel.

| Depending on the requirements and possibilities of a given room, the mixer can be connected to the power supply using a 230V power supply unit or 4 AA batteries. Since the installation does not require any changes in the system, the mixer can be easily installed in an already functioning bathroom.



TOP LEVEL OF FUNCTIONALITY: SALTO MIXER

| Auto-Flushing - the mixer automatically turns itself on for 30 seconds when it has not been used for 24 hours. Thanks to this function, the mixer is rinsed out and protected against bacteria.


| Clean Protect - the possibility of blocking the water flow for 2 minutes (e.g. by cleaning staff) for cleaning purposes.

| Sensor Distance - the possibility of setting the distance at which the sensor reacts to approaching hands.


| Low Battery Reminder - this function informs about low batteries.

| Two temperature adjustment options - available to the user or permanently set in the agitator hidden under the countertop.

| The Salto mixer set also includes a special wrench for the aerator, thanks to which it can be disassembled for cleaning only by dedicated personnel.




SALTO



592-210-00

sensor washbasin mixer with an external agitator



592-200-00

sensor washbasin mixer with an integrated agitator
and a water temperature adjustment knob

SAMBA NEW



592-310-00

sensor washbasin mixer with a water agitator

